Q-225





## **SVE BULLETIN**

## SPECIAL VEHICLE ENGINEERING - BODY BUILDERS ADVISORY SERVICE

E-Mail via Website: <a href="https://www.fleet.ford.com/truckbbas">www.fleet.ford.com/truckbbas</a> (click "Contact Us")

Toll-free: (877) 840-4338

QVM Bulletin: Q-225 Date: 10 September 2014

## **Transit Body Equipment Mounting Manual**

Models Affected: All 2015 MY Transit Vehicles

<u>Description:</u>
The 2015 Transit Body Equipment Mounting Manual (BEMM) has been posted on the 2015 Body Builder Layout Book page of the Body Builder Advisory Service Website. The link is:

https://www.fleet.ford.com/truckbbas/topics/2015/2015 Transit BEMM v1-0.pdf

Vehicle Modifier's/ Body Builder's are advised to review the online version for the most current information prior to starting any conversion.

While it is recommended to review this manual in full, it is suggested to pay attention to these specific points of interest:

1.9.7, 5.13.3	Rear frame extensions	pg. 17, 173
1.11	Load distribution, calculating Center of Gravity	pg. 19
3.2.1	Aux Heat/AC	pg. 33
3.5.1	Exhaust modifications, extensions	pg. 40
3.6.1.3	Aux fuel port (Gas & Diesel)	pg. 46
4.1.12	No Drill Zones — Rear Cargo Area	pg. 55
4.4.6	Additional Loads and Charging Systems	pg. 77
4.11	Exterior Lighting	pg. 99
4.17	Electrical Connectors and Connections	pg. 117
5.1.3	Boron Steel Parts (No drill/ Weld zones)	pg. 133
5.1.4	No Drill Zones — Floor	pg. 135
5.1.5	Integrated Bodies and Conversions (SUB Clearance)	pg. 136
5.1.7	Cutaway (back of cab mounting, floor spacer)	pg. 145
5.5.3	Security, Anti-Theft and Locking System (No Drill)	pg. 153
5.13	Frame and Body Mounting	pg. 170

If you have any questions, please contact the Ford Truck Body Builders Advisory Service as shown in the header of this bulletin.

Originator: BBAS